

HOT DOG STEAMER

PLEASE READ ALL INSTRUCTIONS BEFORE USE

- 1. Position the Hot Dog Steamer on a flat, level surface. (Be careful to protect surface from steam.) Plug cord directly into outlet, do not use an extension cord.
- 2. Add hot water (Distilled water is preferred) to the water pan (in bottom well). Use of hot water will reduce pre-heating time.
- 3. Turn the thermostat control knob to HIGH and turn the steamer on. Wait approximately 30 minutes for the steamer to produce steam.
- 4. Open the bottom door and line bottom shelf with 3-4 rows of stacked, **defrosted** hot dogs. Stacking too many hot dogs in steamer will increase the warming time. (To speed warming and serving time, pre-cook hotdogs before placing in steamer.) Close the unit and wait approximately 60 minutes for the hot dogs to cook.
- 5. Lower the thermostat to the 3 or 4 setting, open the door and add the buns to the bun warmer (on top level). Close the door.
 - After buns are warmed (10-15 minutes) serve hot dogs. ENJOY!!!!
- 6. Continue to add hot water to maintain steam as necessary.
- 7. When finished, unplug machine, remove all food, and empty any remaining water.